ADAPTING THE PAT-4 PHONO PREAMP REPLACEMENT (PAT4PPR) FOR USE IN A PAT5 PREAMP


© 2017 AkitikA, LLC

Revision 1p01   February 8, 2017

Table of Contents

Table of Figures

Section 1: About This Manual

This manual gives the information you need to convert the PAT-4 Phono Preamp for use in a PAT5. The power supply voltages applied will be different, and some values loaded into the PCB will change. Please refer to the PAT-4 PPR manual, and then implement the changes described in the following sections.

PCB Loading Changes

The following different component values are loaded when you adapt the PAT4PPR for use in a PAT-5 preamp.

Desig	PAT4 value	PAT5 value	Color code for PAT5 value	Done✓
R13	27K	18K7	Brown, gray, violet, red, brown	
R26	27K	18K7	Brown, gray, violet, red, brown	
R6	3320	4K99	Yellow, white, white, brown, brown	
R19	3320	4K99	Yellow, white, white, brown, brown	
R7	3320	30K1	Orange, black, brown, red, brown	
R20	3320	30K1	Orange, black, brown, red, brown	
R5	30K1	49K9	Yellow, white, white, red, brown	
R18	30K1	49K9	Yellow, white, white, red, brown	
C7	25V	50V	Both are 47 uF, but the PAT5 rating should 50 Volts	
C20	25V	50V	Both are 47 uF, but the PAT5 rating should 50 Volts	
C27	25V	50V	Both are 47 uF, but the PAT5 rating should 50 Volts	

Powering Changes

Here are the powering changes:
1. Connect the POS17P5 eyelet of the new phono preamp PCB to the 42 volt DC supply on the PAT5 power supply.
2. Connect the NEG17P5 eyelet of the new phono preamp PCB to the -15 volt DC supply on the PAT5 power supply.

Figure 1-Schematic showing value changes for PAT-5 application, page 1

Figure 2-Schematic showing value changes for PAT-5 application, page 2

Value changes for PAT5 Application shown in this red, large type.

30K1
to PAT5 +42V
>=35 V
49K9
4990
Darlington
18K7
to PAT5 -15V